Quick Installation Guide

Cloud Easy Smart Multi-Gigabit Ethernet Switch

WI-CES506GF | WI-CES509GF

www.wireless-tek.com

1. Packing Content

- WI-CES506GF, WI-CES509GF

Switch x 1

Power Adapter x 1

Magnetic Accessory x 4

Quick Installation Guide x 1

2. Hardware Overview

For WI-CES506GF

- Front Panel

- Back Panel



- LED Indicator and Button

LED Indicator/Button	Description
PWR	On: The switch is powered on Off: The switch is powered off or power supply is abnormal
Port 1~4	Green on: Port is connected at 2.5Gbps rate Orange on: Port is connected at 10/100/1000Mbps rate Blinking: Data transmission Off: Port disconnected
Port 5~8	Green on: Port is connected at 10Gbps rate Orange on: Port is connected at 1G/2.5Gbps rate Blinking: Data transmission Off: Port disconnected
Reset	Hold for >9 sec. to restore factory default

- For WI-CES509GF
- Front Panel

- Back Panel



- LED Indicator and Button

LED Indicator/Button	Description
PWR	On: The switch is powered on Off: The switch is powered off or power supply is abnormal
Port 1~8	Green on: Port is connected at 2.5Gbps rate Orange on: Port is connected at 10/100/1000Mbps rate Blinking: Data transmission Off: Port disconnected
SFP indicator(Port 9)	Green on: Port is connected at 10Gbps rate On: Port is connected at 1G/2.5Gbps rate Off: Port disconnected or the port is not connected at 10Gbps/2.5Gbps rate Blinking: Data transmission On: Port is connected at 10Gbps rate Off: Port disconnected or the port is not connected at 10Gbps
Reset	Hold for >5 sec. to restore factory default

3. Installation

- 3.1 Desktop Installation

- 3.2 Wall-mount Installation

Install the Switch by following the steps: Fix 2 screws on the wall to align the 2 fixing holes on the Switch, as shown in the figure below, and hang the Switch smoothly on the screws.

Step1. Use a marker to mark the location of mounting holes on the wall. The two mounting holes should be in the same horizontal line. The spacing between the screws matching the spacing between the two fixing holes of the switch.



Step2. Fix 2 screws on the wall. Leave the screws at least 1.5mm outside the wall to ensure that the switch can be firmly hung on the screws.



Step3. Fasten the switch to the screws through the two installation holes at the bottom of the switch. Place the switch ports side down, and the two sides of the switch are perpendicular to the ground.

Step 2. Attach the switch installed with magnetic absorption accessories to a suitable installation position.

- 3.3 Magnetic-mount Installation

The switch can be installed in magnetic mode, and devices can be attached to iron desktops or walls.

Step 1. Insert the countersunk screw through the center round hole of the permanent magnet using a Phillips screwdriver and secure it to the blind hole nut at the bottom of the switch.

4.Management

- **Log in to the switch locally**

Let the Switch obtain an IP address and then check the DHCP server to see which IP address was assigned.
The Switch is set to DHCP by default, so it will try to obtain an IP address automatically. If that fails, then it will use the default fallback **IP address, 192.168.0.1**.

To log in, follow these steps:
1.Launch your web browser. Type the appropriate IP address in the address field.
2.The login screen will appear. In the factory state, the first login requires setting an account and password.

- **Cloud login switch configuration**

1. Log in to the cloud management page
(No account, you need to register an account to log in, The URL is http://cloud2.wireless-tek.com)

2. Enter the cloud binding switch

1)Explain: The switch must be connected to the Internet to bind successfully)

Please enter the device serial number and the last six hexes of the device MAC address to bind a device to the current group, device can be diff when binding.

1)Explain: The 1-7-digit SN code and MAC address of the switch are shown on the sticker on the back of the switch as shown in the figure below)

3. After binding, you can use the Switch in the Tunnel option in the cloud management, and then use EWEB to enter the switch.

The Switch can be managed via an Ethernet interface connected to the Internet or by connecting directly to a computer running the Web browser, such as cloud L2, L3 management switch, gateway, wireless AP, etc.)



Warranty Card

Username	
Address	
Telephone No.	
Purchase Shop	
Purchase Address	
Product Model No.	
Purchase Time	
Serial No.	
Dealer Signature	

- If the product defects within the warranty period, we will provide professional maintenance service.
- Proof of purchase and a complete product serial number are required to receive any warranty service within the warranty period.
- Any other defects that are not caused by workmanship or product quality, such as natural disasters, water damage, extreme thermal or environmental conditions, sticker damaged, warranty card loss will disqualify the product from limited warranty.

Customer support | Compare Models | Cloud Management

Wireless-Tek Technology Limited
Address: Building 3, Units 1901~1901, 1912,
Huaqiang Eco-Park, Tangwei Community,
Fuhai Street, Bao'an District, Shenzhen City,
Guangdong Province, China.
Website: www.wireless-tek.com
Tel: 86-0755-3291 1299
Email: sales@wireless-tek.com
Technical Support: tech@wireless-tek.com

CE FC RoHS UK CA