Quick Installation Guide

Cloud L3 Managed 10G Switch

WI-CMS6006F-L3

www.wireless-tek.com

1. Packing Content

- WI-CMS6006F-L3

Switch x 1

Quick Installation Guide x 1

Serial Line x 1

Power Adapter x 1

Mounting Accessories

Magnetic Accessory x 4, Mat x 4,2

2. Hardware Overview

For WI-CMS6006F-L3

- Front Panel

- Back Panel

- LED Indicator and Button

Item	Status	Description
PWR	/	Off: The device is power off or failed On: The device power is on
Link	Off	No device is connected to the corresponding port
	Blinking	Indicates that the Switch is actively sending or receiving data over that port
	Green	Indicates 100 link
	Orange	Indicates 1GbE/2.5GbE/5GbE/10GbE link
SYS	Green	Blinking: The system is running normally Always on or off: The system is abnormal Blinking: The system is working normally
SFP+	Off	No device is connected to the corresponding port
	Blinking	Indicates that the Switch is actively sending or receiving data over that port
	Green	Indicates 1GbE link
	Orange	Indicates 10GbE/2.5G link
Reset	/	Hold on over 5 seconds to restore the device to the factory

3. Installation

- 3.1 Desktop Installation

- 3.2 Wall-mount Installation

Install the Switch by following the steps: Fix 2 screws on the wall to align the 2 fixing holes on the Switch, as shown in the figure below, and hang the Switch smoothly on the screws.

Step 1. Use a marker to mark the location of mounting holes on the wall. The two mounting holes should be in the same horizontal line. The spacing between the screws matching the spacing between the two fixing holes of the switch.

Step 2. Fix 2 screws on the wall. Leave the screws at least 1.5mm outside the wall to ensure that the switch can be firmly hung on the screws.

Step 3. Fasten the switch to the screws through the two installation holes at the bottom of the switch. Place the switch gently side down, and the two sides of the switch are perpendicular to the ground.

- 3.3 Magnetic-mount Installation

The switch can be installed in magnetic mode, and devices can be attached to iron desktops or walls.

Step 1. Insert the countersunk screw through the center round hole of the permanent magnet using a Phillips screwdriver and secure it to the blind hole nut at the bottom of the switch.

Step 2. Attach the switch installed with magnetic absorption accessories to a suitable installation position.

4. Configuration

First, please power on the switch and make sure it is connected to the Internet. Then connect the PC to the switch.

- Log in to the switch locally

Let the switch obtain an IP address and then check the DHCP server to see which IP address was assigned.

The switch is set to DHCP by default, so it will try to automatically obtain an IP address. If that fails, then it will use the default fallback IP address, **192.168.0.1**

To log in, follow these steps:

1. Launch your web browser: you type the appropriate IP address in the address bar.
2. The login screen will appear. In the factory state, the first login requires setting an account and password.

- Use the console cable to access the switch

Connection Diagram:

Step 1 Download a PuTTY software

Step 2 Use the Console cable to connect the computer and the switch as shown in the figure below.

Step 3 Get the com port number of the Console line and the baud rate of the switch in the software (steps as shown in the figure below):

Notice:

Step 2 is your computer recognizes the COM number of the Console line

Step 3 is the baud rate of the switch (the default rate of the switch is 9600)

Note: The first login requires setting up an account and password.

- Cloud login switch configuration

1. Log in to the cloud management interface

(No account, you need to register an account to log in. The URL is: https://cloud2.wireless-tek.com)

2. Enter the cloud binding switch

(Guarantee that the device is connected to the internet to bind successfully)

Please enter the device serial number and MAC address to bind a device to the current group, device can be off when binding.

The device SN and MAC address of the switch is shown on the sticker on the back of the switch as shown in the figure below:

3. After binding, you can use the switch in the Tunnel option In the cloud management, and then choose to use EWEB or TELNET to enter the switch.

(After entering the switch, you can configure it based on your own needs)

Warranty Card

Username	
Address	
Telephone No.	
Purchase Shop	
Purchase Address	
Product Model No.	
Purchase Time	
Serial No.	
Dealer Signature	

- If the product defects within the warranty period, we will provide professional maintenance service.
- Proof of purchase and a complete product serial number are required to receive any service that are guaranteed as part of warranty.
- Any other defects that are not caused by workmanship or product quality, such as improper operation, unauthorized modification or use outside the product's specifications, or normal wear and tear, are not covered by warranty and loss will disqualify the product from limited warranty.

Wireless-Tek Technology Limited

Address: Building 5, Units 1901-1 &1911, 1912,

Huaqiang Era Plaza, Tangwei Community,

Fuhai Street, Bao'an District, Shenzhen City,

Guangdong Province, China.

Website: www.wireless-tek.com

Tel: 86-0755-33911386

Email: sales@wireless-tek.com

Technical Support: techfae@wireless-tek.com

Scan to Download Quick Guide

CE FC RoHS